FencePlus

Fence Post Light Installation Instructions

Insert 3-end power cable into the aluminium top cover.

01

Fix the brackets onto the ends of top cover with screws.

02

×N

AC 110~240

03

Slide the aluminium top cover with power cable into the posts.

04

Connect the 3-end power cable with power supply cable.

05

Cut the post side cover into certain length and slide into the post.

06

**Insert the fencing light into post.**

07

Slide the short post side cover into the post to cover the slot.

08

Connect the fencing light with 3-end power cable.

09

**Insert the rest part of the cable into the post, and cover the post cap properly.**

10

Finish.

11

Lamp ×1   Power Cable ×1

Input Voltage	Working Voltage	LED Quantity	Rated Power	Luminous Flux	Optical Angle
AC 110~240V	DC 24V	2 pcs	2 W	139 lm	20×50°

greensquares
The Ultimate Outdoor Living Space

www.greensquares.co.uk/fenceplus